

<b>Bilmärke:</b>	<b>Modell:</b>	<b>Takskyltsbredd</b>	<b>Takräckesbredd</b>
<b>Citroen</b>			
	Berlingo	1300mm	1300mm
	Jumpy	1300mm	1400mm
	Jumper	1500mm	1600mm
	Nemo	1300mm	1300mm
<b>Fiat</b>			
	Doblo	1300mm	1400mm
	Ducato	1500mm	1600mm
	Fiorino	1300mm	1300mm
	Scudo	1300mm	1400mm
	Talento	1500mm	1600mm
<b>Ford</b>			
	Connect	1300mm	1300mm
	Courier	1300mm	1300mm
	Custom	1500mm	1600mm
	Transit	1500mm	1600mm
<b>Mercedes</b>			
	Citan	1300mm	1300mm
	Sprinter	1500mm	1600mm
	Vito	1500mm	1500mm
<b>Nissan</b>			
	NV200	1300mm	1400mm
	NV300	1500mm	1600mm
	NV400	1500mm	1600mm
<b>Opel</b>			
	Combo	1300mm	1400mm
	Movano	1500mm	1600mm
	Vivaro	1500mm	1600mm
<b>Peugeot</b>			
	Boxer	1500mm	1600mm
	Expert	1300mm	1400mm
	Partner	1300mm	1300mm
<b>Renault</b>			
	Kangoo	1300mm	1300mm
	Master	1500mm	1600mm
	Trafic	1500mm	1600mm
<b>Toyota</b>			
	Proace	1300mm	1400mm
<b>VW</b>			
	Caddy	1300mm	1300mm
	Crafter	1500mm	1600mm
	Transporter	1500mm	1500mm
<b>Volymskåp osv</b>			
		1700mm	1700mm -->
		1900mm	1900mm -->
		2100mm	2100mm -->
		2300mm	2300mm -->